

Materials, Tools, and Supplies Needed.

* = May possibly need.

Use **Concrete Camouflage**® brand,

Concrete Stain / Clear Shield™ **Concrete Sealer** / Top Shield™ **Wax** or Clear Grip™ **Traction Additive**.

Supplies Needed to Protect Walls, Doors, etc.

- Tape & Plastic. We recommend the kind that has the blue tape already attached to the plastic, which is folded to about 4" wide. The plastic is about 24" tall and is unfolded upward after applying the tape at the bottom.

Supplies Needed to Protect Yourself.

- Protective wear for yourself, including proper clothing, shoes, masks, goggles, gloves, and respiratory protection as needed. (NIOSH/MSHATC23C or equivalent.)
- Common Sense and a Safe and Unhurried Attitude.

Supplies and Tools Needed to Score. (You could use a helper or two here.)

- Tape Measure.
- Pencil.
- Chalk line w/ blue chalk.
- Extension Cord.
- 4 1/2" grinder or Skill saw with diamond blade.
- Straight edge to keep the saw or grinder straight.
- *Square.

Supplies and Tools Needed to Clean.

- *Water Hose.
- T.S.P. and a 5 gallon bucket.
- Rags.
- Soft Bristle Push Broom, Mop, Bucket, and/or Wet Vacuum.
- *Xylene, Citrus cleaners, strippers, mastic removers. (Depending on extent of cleaning needed.)
- *Scrub brushes.
- *Scrapers.
- *Kneepads.
- *Sander, if the surface needs it.
- *Concrete Patch material if needed.
- *Concrete Trowel and rubbing stone if patching.

Supplies and Tools Needed to Apply Concrete Stain.

- Small cheap 1 gallon all plastic pump up sprayer.
- *Brush w/ handle. (Very Soft bristle, like the ones at the carwash.)
- *Paint brush
- *Bucket or empty plastic ice cream bucket maybe.
- Rags or old towels for the entry/exit point. (To keep from tracking dirt in or stain out.)
- *Caution tape or warning signs to keep off.
- Brooms, Mops, and Buckets for cleaning residue.
- Ammonia to neutralize the stain. Mix 1 cup ammonia to 5 gallons of water. (Or you can use T.S.P. and water.)

Supplies and Tools Needed to Apply Clear Shield™ Concrete Sealer.

- Roller cage w/ handle and covers. (Paint Rollers)
- Adequate Ventilation.
- No open flame or ignition source. This includes pilot lights from gas appliances such as heaters, stoves, etc.
- *Sealer tint if desired. Only used for camouflaging a very bad slab.
- *Electric drill w/ paint stirrer rod. (If using grip additive)
- Paint pan (If not using the 5 gallon pail.)

Supplies and Tools Needed to Apply Top Shield™ Wax.

- Lambs wool applicator (Recommended), or synthetic wax applicator, or sponge mop. w/ handle.
- Paint pan.